

FS Future Serie®

Cavefinder

User's manual

Any information contained in these operating instructions may be changed without prior notice.

OKM does not make any warranty for this document. This also applies without limitation to implied assurances of merchantability and fitness for a specific purpose. OKM does not assume any responsibility for errors in this manual or for any incidental or consequential damage or loss associated with the delivery, exploitation or usage of this material.

This documentation is available „*as presented*“ and without any kind of warranty. In no circumstances OKM takes responsibility for lost profits, usage or data losses, interruption of business activities or all kind of other indirectly damages, which developed because of errors in this documentation.

This instruction manual and all other stored media, which are delivered with this package should only be used for this product. Program copies are allowed only for security- and safety purposes. The resale of these programs, in original or changed form, is absolutely forbidden.

This manual may not be copied, duplicated or translated into another language, neither in part nor completely, over the copyright matters without the prior written consent of OKM.

Copyright ©2002 – 2007 OKM Ortungstechnik GmbH. All rights reserved.

Contents

1 Preface	6
2 Important Notes	7
2.1 General Notes	7
2.2 Possible Health Hazards	7
2.3 Surrounding Area	7
2.4 Voltage	7
3 Technical Specifications	8
3.1 Control Unit	8
3.2 Data Transmission	8
3.3 Computer, Minimum Requirements	9
4 Scope of Delivery	10
5 Assembly	12
6 Installation of Radio Transmission (Toshiba)	14
6.1 Install Software & Drivers	14
6.2 Software Configuration	17
6.3 Configure connection	18
7 Installation of Radio Transmission (Conceptronic)	19
7.1 Windows XP, 2000, ME und 98SE	19
7.1.1 Install Software & Drivers	19
7.1.2 Install Bluetooth-Dongle	23
7.1.3 Configure connection	26
7.2 Windows Vista	27
7.2.1 Install Bluetooth-Dongle	27
7.2.2 Establish connection	30
8 Control Elements	32
8.1 Front View	32
8.2 Back View	33
8.3 Touchpad for Menu Navigation	34
9 Detection of Cavities	35
10 Danger of Explosion during Excavation	37
11 Maintenance and Services	38

List of Figures

1	Scope of Delivery	11
2	Connection of Electrodes	12
3	Connection of External Power Supply	12
4	Connection of USB Dongle	13
5	Bluetooth-Installation	14
6	Bluetooth-Installation, Select Language	14
7	Bluetooth-Installation, Start	15
8	Bluetooth-Installation, Licence Agreement	15
9	Bluetooth-Installation, Setup	16
10	Bluetooth-Installation, Finish	16
11	Bluetooth-Installation, Reboot	17
12	Determining the given COM-Port	17
13	18
14	Bluetooth-Installation	19
15	Bluetooth-Installation, Select Language	19
16	Bluetooth-Installation, Start	20
17	Bluetooth-Installation, Licence Agreement	20
18	Bluetooth-Installation, Destination Folder	21
19	Bluetooth-Installation, Setup	21
20	Bluetooth-Installation, Finish	22
21	Bluetooth-Installation, Reboot	22
22	Bluetooth-Installation, Plug in the Bluetooth-Dongle	23
23	Bluetooth-Installation, Set up Bluetooth-Dongle	23
24	Bluetooth-Installation, Bluetooth-Dongle has been installed	23
25	Find out the assigned COM-Port	24
26	Find out the assigned COM-Port	24
27	Find out the assigned COM-Port	25
28	USB-Connection, Enter PIN-Code	26
29	USB-Connection, Confirm Access	26
30	USB-Connection, Connection established	26
31	Windows Vista, Install Bluetooth-Dongle	27
32	Windows Vista, Set up Bluetooth-Dongle	27
33	Windows Vista, Configurate Bluetooth-Dongle	27
34	Windows Vista, Verify Bluetooth settings	28
35	Windows Vista, Configurate serial COM-Port	28
36	Windows Vista, Configurate serial COM-Port	29
37	Windows Vista, Allow access	30
38	Windows Vista, Set up Bluetooth-Dongle	30
39	Windows Vista, Finish connection assistant	31
40	Windows Vista, List of Bluetooth devices	31
41	Front View	32
42	Back View	33
43	Touchpad for Menu Navigation	34
44	Connection of Electrodes	35
45	Rarefy a Measurement	36

List of Tables

1	Technical Specifications (Control Unit)	8
2	Technical Specifications (Data Transmission)	8
3	Technical Specifications (Computer, Minimum Requirements)	9
4	Scope of Delivery	10

1 Preface

Dear customer,

in the first instance we want to thank you that you made your decision on a product of OKM Ortungstechnik GmbH.

The present product is based on a geo-electric measuring method which can be used to locate cavities in the target area. This is including not only natural but also man-made cavities.

With our team of specialists we guarantee that our products are under recurrent control. Our specialists try to implement new developments in terms of further quality improvements for you.

Of course by selling our products we cannot guarantee that you really make a find during your research. The recognition of hidden objects and structures depends on a hugh number of factors - like you know. Determining factors are the dielectricity constant of the ground, the grade of mineralisation and the dimensions of an object relating to its depth. Specially in very wet soil, clay and sand with high conductivity of the ground, recording of the measured results can be falsified strongly.

With this product you purchased a device which stood the tests in regular operation like all other products of us. If you are interested in where our devices have gone into action please visit our homepage.

For our company it is necessary that we protect our developments within the framework of existing legislation to a patent or trademark registration. Therewith we offer you a higher warranty while using our products.

Please take your time consecutively, read this user's manual and familiarize yourself with the utilisation and operation of this Cavfinder.

2 Important Notes

Please read these operating instructions carefully and closely before using *Cavefinder* and its accessories! These instructions give information on how to use the device and point out potential sources of danger.

2.1 General Notes

Being an electronic device, *Cavefinder* has to be treated with the caution and care necessary when such devices are used. Any failure to observe the safety precautions given or any use for purposes other than the ones it is conceived for may result in a damage or destruction of the processing unit and connected components.

The device will get destroyed if it is opened improperly.

2.2 Possible Health Hazards

If used properly the device normally does not pose any health hazards. According to current scientific knowledge, the high-frequency signals are not harmful to the human body on account of their low power.

2.3 Surrounding Area

Having been transferred from a cold to a warmer place, the device should not be operated immediately afterwards. Any condensation, which may have formed, might cause the device to get destroyed. Avoid strong magnetic fields, which may occur in places such as near machines or loudspeakers, and avoid using a detector within a radius of 50 meters.

2.4 Voltage

The power supply should not be outside the indicated range of values. Use only chargers, batteries and rechargeable batteries which are included in the scope of delivery.

Never use the 230 Volt mains supply.

3 Technical Specifications

The following technical indications are medial values. During operation small variations are quite possible.

3.1 Control Unit

Dimensions (H x W x D)	430mm x 150mm x 260mm
Weight	about 3kg
Voltage	12 VDC
Processor	Motorola, 4 MHz
Operating Temperature	0°C – 50°C
Storage Temperature	-20°C – 60°C
Air Humidity	5% – 75%
Waterproof	No

Table 1: Technical Specifications (Control Unit)

3.2 Data Transmission

The following specifications of data transmission are only valid for the model *Cavfinder B*. The *Cavfinder A* does not have a data transmission.

Technology	Bluetooth
Frequency	2.4 – 2.4835 GHz
Maximal Data Transmission Rate	1 Mbps
Receiving Sensitivity	-85 dBm
Maximal Range	about 100 meters

Table 2: Technical Specifications (Data Transmission)

3.3 Computer, Minimum Requirements

The computer is not part of the scope of delivery. The indicated values should help you for a correct selection of a suitable computer for analysis of your measured results.

A computer is only necessary for the usage of *Cavefinder B*. The model *Cavefinder A* does not provide data transmission to pc.

CD-ROM Drive	minimum 4x
COM-Port (Data Transmission)	USB
Free Memory	minimum 20 MB
Working Memory (RAM)	minimum 128 MB
Graphic Card	minimum 64 MB, OpenGL-compatible
Operating System	Windows 98SE, Me, 2000, XP

Table 3: Technical Specifications (Computer, Minimum Requirements)

4 Scope of Delivery

In the following section you can find all standard equipment. The scope of delivery can be different in some circumstances because of some optional accessories which should not be included in the basic equipment.

- 1 Control Unit
- 4 Electrode (with about 20m cable)
- 1 User's Manual
- 1 External Power Supply
- 1 Charger for External Power Supply
- 1 Cable for External Power Supply
- 1 Carrying Case
- 1 3D Software (standard)*
- 1 USB Bluetooth Dongle*
- 1 USB Setup CD*


* only Cavfinder B;

Table 4: Scope of Delivery

Beware that pictures in this manual could be different to delivered parts.



Control Unit



Electrode



USB Bluetooth Dongle *



External Power Supply



Charger for External Power Supply



Cable for External Power Supply

Figure 1: Scope of Delivery

5 Assembly

In this section is explained how to assemble the device and how to prepare a measurement.



Figure 2: Connection of Electrodes

In figure 2 you can see how to connect the electrodes to the device in the right way. Do it without any unnecessary application of force! The detailed discription how to connect the electrodes you can find in section 9 on page 35.



Figure 3: Connection of External Power Supply

In figure 4 you can see how the external power supply has to be connected. Please take care that you use the 12V output of the external power supply for the correct cable connection.

With the model *Cavfinder B* you have the possibility to transfer all measured values to a computer. In figure 4 you can see, how to connect the Bluetooth Dongle with the USB-Port of your computer. Further information about the correct utilisation and installation of the USB driver you can find in section 6 for Toshiba driver or in section 7 for Conceptronic driver.



Figure 4: Connection of USB Dongle

6 Installation of Radio Transmission (Toshiba)

This section describes the installation of the USB Bluetooth Dongle. Consider that the represented figures not necessarily agree with the current version of your operating system or the version of your USB installation.

The instructions in this chapter are only valid for the Toshiba usb-drivers. If you are using the Conceptronic usb-drivers, please read chapter 7.

6.1 Install Software & Drivers

Now it is time to install the software and driver on your system. Therefore you have to insert your Bluetooth CD into the CD ROM drive of your computer. If the CD does not start automatically, please double click on Desktop and then double click on the symbol of your CD ROM drive. With a further double click on file `setup.exe` you start the installation.



Figure 5: Bluetooth-Installation

The first window of your installation will open. Click here on the entry *Toshiba Driver* and follow the instructions on the screen.




Figure 6: Bluetooth-Installation, Select Language

First there is a possibility to select the language of the installation. Click on *OK*, to change to the installation dialog from figure 7.




Figure 7: Bluetooth-Installation, Start

Now simply click on *Next*, to continue the installation. A dialog like in figure 8 appears on your screen.



Figure 8: Bluetooth-Installation, Licence Agreement

Select the option *I accept the terms in the licence agreement* and confirm it with a click on *Next*.




Figure 9: Bluetooth-Installation, Setup

Click now on the button *Install*, to start to copy the files. Afterwards you will be referred that the installation process can take about 15 minutes. Answer this question with a click on *OK*. If you did not connect the Bluetooth Dongle until now you will be asked to do so during the installation of the driver. Now wait until the installation is finished and all files has been transferred to your computer.




Figure 10: Bluetooth-Installation, Finish

As soon as the installation is finished, a dialog as in figure 10 appears. Click on the button *Finish*.




Figure 11: Bluetooth-Installation, Reboot

To terminate the installation you have to reboot your computer. A message like in figure 11 will appear. Confirm it with a click on the button *Yes*.

6.2 Software Configuration

To find out on which COM-Port your Bluetooth connection is been installed, click on *Start* → *Settings* → *Control Panel*. Double click the entry *Bluetooth Local COM*. A dialog will open like it is represented in figure 12.




Figure 12: Determining the given COM-Port

There you can find the entry *LocalCOM-Server[SerialPort(TOSHIBA LocalCOM)]*, which indicates on which COM-Port your Bluetooth Dongle has been installed. This COM-Port you always have to indicate for the data transmission to the software program.

6.3 Configure connection

After installation and configuration of your Bluetooth connection you should test if the data transmission from your measuring instrument to the computer is working correctly.

Be sure that the USB Dongle is attached to your computer. Take your measuring instrument and power on the device. Select a operating mode, which includes the direct data transmission to PC. Additional information on direct data transmission to PC you can find in section 9 on page 35.




Figure 13:

As soon as you confirm your selected operating mode the device will try to get a radio connection to the computer. If this connection is successful a message like in figure 13 appears.

In this dialog you have to enter OKM. It is necessary to write in capital letters!

7 Installation of Radio Transmission (Conceptronic)

This section describes the installation of the USB Bluetooth Dongle. Consider that the represented figures not necessarily agree with the current version of your operating system or the version of your USB installation.

The instructions in this chapter are only valid for the Conceptronic usb-drivers. If you are using the Toshiba usb-drivers, please read chapter 6.

7.1 Windows XP, 2000, ME und 98SE

7.1.1 Install Software & Drivers

Now it is time to install the software and driver on your system. Therefore you have to insert your Bluetooth CD into the CD ROM drive of your computer. If the CD does not start automatically, please double click on Desktop and then double click on the symbol of your CD ROM drive. With a further double click on file `autorun.exe` you start the installation.




Figure 14: Bluetooth-Installation

The first window of your installation will open. Click here on the entry *1 Install drivers and application software* and follow the instructions on the screen.



Figure 15: Bluetooth-Installation, Select Language

First there is a possibility to select the language of the installation. Click on *OK*, to change to the installation dialog from figure 16.




Figure 16: Bluetooth-Installation, Start

Now simply click on *Next*, to continue the installation. A dialog like in figure 17 appears on your screen.



Figure 17: Bluetooth-Installation, Licence Agreement

Select the option *I accept the terms in the licence agreement* and confirm it with a click on *Next*.




Figure 18: Bluetooth-Installation, Destination Folder

Inside the dialog from figure 18 you have the possibility to select another destination folder. Normally there is no changing necessary. Click only on the button *Next*.




Figure 19: Bluetooth-Installation, Setup

Click now on the button *Install*, to start to copy the files. Now wait until the installation is finished and all files has been transferred to your computer.




Figure 20: Bluetooth-Installation, Finish

As soon as the installation is finished, a dialog as in figure 20 appears. Click on the button *Finish*.




Figure 21: Bluetooth-Installation, Reboot

To terminate the installation you have to reboot your computer. A message like in figure 21 will appear. Confirm it with a click on the button *Yes*.

7.1.2 Install Bluetooth-Dongle

After you have reboot the computer the message from figure 22 appears on your screen. Now you have to plug in the Bluetooth-Dongle into your computer.




Figure 22: Bluetooth-Installation, Plug in the Bluetooth-Dongle

Now your computer tries to install automatically the Bluetooth-Dongle. Wait until a dialog window like in figure 23 appears on your screen. Click on the button *OK*.



Figure 23: Bluetooth-Installation, Set up Bluetooth-Dongle

After a successful set up of the Bluetooth-Dongle the message from figure 24 appears on your screen.



Figure 24: Bluetooth-Installation, Bluetooth-Dongle has been installed

To find out on which COM-Port the Bluetooth connection has been installed you have to click with the right mouse button on the Bluetooth symbol in the task bar. A dialog window like in figure 25 will appear.




Figure 25: Find out the assigned COM-Port

If you click here on the entry *Display* a window like represented in figure 26 will open. Select in the menu *View* the option *Service Window*.




Figure 26: Find out the assigned COM-Port

An image like in figure 27 is represented. Behind the indication *Serial Port A* you can read the number of the assigned COM-Port. In this figure it is *COM7*, this can be different on your computer!




Figure 27: Find out the assigned COM-Port

7.1.3 Configure connection

After installation and configuration of your Bluetooth connection you should test if the data transmission from your measuring instrument to the computer is working correctly.

Be sure that the USB Dongle is attached to your computer. Take your measuring instrument and power on the device. Select a operating mode, which includes the direct data transmission to PC. Additional information on direct data transmission to PC you can find in section 9 on page 35.




Figure 28: USB-Connection, Enter PIN-Code

As soon as you confirm your selected operating mode the device will try to get a radio connection to the computer. If this connection is successful a message like in figure 28 appears. In this dialog you have to enter OKM. It is necessary to write in capital letters! Confirm this entry by a click on the button *OK*.



Figure 29: USB-Connection, Confirm Access

Another window will open where you mark the entry *Always allow this device to access this service* and confirm this entry by a click on *Yes*.




Figure 30: USB-Connection, Connection established

The message from figure 30 indicates that the connection is established. Now you have set up successfully your Bluetooth connection.

7.2 Windows Vista

For Windows Vista there are no additional drivers necessary. The basic functions are already provided by the operating system. To install the Bluetooth-Dongle on your Windows Vista system, please read the instructions in the following subsection!

7.2.1 Install Bluetooth-Dongle

Power on your computer and wait until Windows Vista is completely booted. After you signed up for your Windows Vista system plug in the Bluetooth-Dongle into a free USB slot. The message from figure 31 appears on your screen.




Figure 31: Windows Vista, Install Bluetooth-Dongle

Wait a little moment until the installation of the Bluetooth-Dongle is completed successfully and the message from figure 32 appears on your computer screen.





Figure 32: Windows Vista, Set up Bluetooth-Dongle

To use the Bluetooth-Dongle with your device, you have to apply a serial COM-Port. Therefore please click with the right mouse button on the Bluetooth symbol  on the down right side of your computer screen! A dialog similar to figure 33 will open. Click with the left mouse button on the entry *Open Bluetooth settings*.




Figure 33: Windows Vista, Configure Bluetooth-Dongle

The dialog window from figure 34 will open. Click with the left mouse button on the tab *Options* and compare the settings of your computer with those from the figure. After that please click on the tab *COM-Ports*.

To transfer the measured data from your device to the computer, you have to establish now the serial COM-Port. The figure 34 (right side) shows the relevant dialog window. Click with the




Figure 34: Windows Vista, Verify Bluetooth settings

left mouse button on the button *Add*. Another dialog window like represented in figure 35 will open.




Figure 35: Windows Vista, Configure serial COM-Port

In this dialog you only have to select option *Incoming (Device initiate connection)* and confirm your selection by a click on the button *OK*. Automatically a serial COM-Port will be created and a Port referred. In this tutorial the Port *COM3* has been referred. This Port *COM3* has to be entered later in the software, to transfer measured data to your computer.




Figure 36: Windows Vista, Configure serial COM-Port

Again, in figure 36 the allocation of the serial COM-Port *COM3* is represented. The installation of the Bluetooth-Dongle is now completed. The next step is to establish a test connection, to control the connectivity.

7.2.2 Establish connection

Be sure that the Bluetooth-Dongle is plugged into your computer. Now take your measuring instrument and power it on. Select an operating mode which supports the direct data transfer to your PC. Detailed information you can find in section 9 on page 35. As soon as you confirmed this function on your device, a radio connection to your pc will be established. If it is successful the dialog from figure 37 appears.




Figure 37: Windows Vista, Allow access

Click with the left mouse button inside this message to enter the PIN-Code. A dialog like in figure 38 appears on your computer screen.



Figure 38: Windows Vista, Set up Bluetooth-Dongle

There please enter the PIN-Code OKM. Take care to use capital letters! Confirm the entry by a click on the button *Next*.




Figure 39: Windows Vista, Finish connection assistant

After a connection has been established the dialog from figure 39 appears. Just click on the button *Finish* to finish the connection assistant.




Figure 40: Windows Vista, List of Bluetooth devices

To find out the current status of your Bluetooth-Dongle click with the right mouse button on the Bluetooth symbol inside the down right corner of your screen. In the following menu (see figure 33 on page 27) please click with the left mouse button on the entry *Open Bluetooth settings*. A dialog like in figure 40 shows all existing devices. As soon as one of these devices has established a connection it will be indicated by the supplement *Connected*.

8 Control Elements

In this section you will learn more about the fundamental use of all control elements for this measuring instrument. All connections, inputs and outputs are explained in detail.

8.1 Front View

Figure 41 shows the front side of the device.




Figure 41: Front View

The Power On and Off Button is used to switch on and off the control unit. Before operating with your device you have to be sure that the device is charged.

The Operating Lamp shines, when the device is powered on and indicates the operating readiness of the control unit.

The LCD Display indicates how often the device was powered on. This display is only of interest for the repair and maintenance service.

On the Connection of External Power Supply the external battery has to be connected. Be sure that the battery is full charged before operation.

8.2 Back View

Figure 42 shows the back side of the control unit with all connections.




Figure 42: Back View

The Connection for Electrodes is used to connect the delivered electrodes for cavity detection.

The Antenna for Bluetooth is used for the data transmission to a connected pc and exists only for *Cavefinder B*.

8.3 Touchpad for Menu Navigation

The top of the device is including a touchpad like in figure 43. The represented buttons have no particular use in both models of the Cavfinder and are not necessary for operating the device.




Figure 43: Touchpad for Menu Navigation

9 Detection of Cavities

The *Cavefinder* offers you a geo-electrical measuring method to detect all kind of cavities. The device is not able to determine the exact depth of a located cavity.

There are four connections for the electrodes on the control unit. You have to keep a certain manner to connect the electrodes in the right way. The correct connection is represented in figure 44.




Figure 44: Connection of Electrodes

Try to define a square area with the four electrodes and connect the cables to the main unit. Therefore you have to plug in the electrode cable of the upper left electrode in the first connection of the device from left to right. The following electrode cable which is placed next to it counter clockwise has to be plugged into the next connection. Go on in the same direction until all electrodes are connected.

To perform a measurement plug in the electrodes like explained above and connect them in the correct way. Power on the device and wait until the result is represented on the display. If a cavity is been detected inside your defined area the message *Cave = Yes* appears on the display, if there is no cavity the message *Cave = No* will be shown.

If this is your first measurement it is advised to define a wide area to find out in generally if there

is a cavity or not. To detect the exact location of a cavity (if a cavity exists) split your measured field in four smaller parts and repeat the measurement in every subsection. This method you can repeat as often as you like until you found the exact location of the cavity.




Figure 45: Rarefy a Measurement

In figure 45 the explained measuring method is represented once again. At first measure the wide area which is here represented in black color. On the display of the device the message *Cave = Yes* appears. Then divide this area in four smaller subsections and repeat your measurement inside these red represented fields again. Only in the upper left field the result *Cave = Yes* will be shown. All other fields will indicate the message *Cave = No* on the display. Now you can split this red marked subsection again to specify the position and size of the detected cavity.

With model Cavfinder B additionally you can transfer data to a connected computer. The measured data will only be transferred to a pc if the result is Cave = Yes. As a correct number of impulses you have to enter 4 when you prepare the software program. Further information about the software you can find in the appropriate user's manual for software!

10 Danger of Explosion during Excavation

Unfortunately, the last two world wars also made the ground in many places of the world a potentially explosive scrap heap. A host of those lethal relics are still buried in the ground. Do not start digging and hacking for an object wildly when you receive a signal of a piece of metal from your device. Firstly, you might indeed cause irreparable damage to a truly rare find, and secondly, there is a chance that the object reacts in an insulted way and strikes back.

Note the colour of the ground close to the surface. A red or reddish color of the ground is an indicator of rust traces. As regards the finds themselves, you should definitely pay attention to their shape. Curved or round objects should be a sign of alarm, especially if buttons, rings or little pegs can be identified or felt. The same applies to recognizable ammunition or bullets and shells. Leave that stuff where it is, do not touch anything and, most importantly, do not take any of it home with you. The killing machines of war made use of diabolical inventions such as rocker fuses, acid fuses and ball fuses. Those components have been rusting away in the course of time, and the slightest movement may cause parts of them to break and be triggered. Even seemingly harmless objects such as cartridges or large ammunition are anything but that.

Explosives may have become crystalline over time, that is, sugar-like crystals have formed. Moving such an object may cause those crystals to produce friction, leading to an explosion. If you come across such relics, mark the place and do not fail to report the find to the police. Such objects always pose a danger to the life of hikers, walkers, farmers or children.

11 Maintenance and Services

In this section you will learn how to maintain your measuring instrument with all included accessories to keep it in good condition a long time and to get good measuring results.

The following list indicates what you absolutely should avoid:

- penetrating water
- strong dirt and dust deposits
- hard impacts
- strong magnetic fields
- high and long lasting heat effect

If you want to clean your device please use a dry rag of soft material. To avoid any damage you should transport the device and accessories always in the appropriate carrying cases.

Beware that all batteries and accumulators are always charged fully while operating with your system. You should only load the batteries when they are completely discharged no matter if you are working with the external power supply or with the internal accumulators. In this way a long durability of the used batteries is guaranteed.

To load the external and internal batteries you have to use only chargers which are part of our scope of delivery.

Index

Bluetooth, 14, 19

Bluetooth-Dongle, 23, 27, 29–31

Dongle, 14, 19

PIN-Code, 30

Power Supply, 12

USB, 14, 19